



MonoFoil[®] Antimicrobial



MonoFoil[®] Technology Laundry Directions

Bacteria, fungi, yeasts, algae: they are all micro-organisms which can only be seen through a microscope, can survive the washing process, even after a 145° F (62° C) wash. **MonoFoil[®] Antimicrobial** works even at low temperatures, which means that you don't have to wash at 160° F (70° C) to eliminate germs.

MonoFoil[®] Usage Guidelines

Load Treated Pounds	MonoFoil [®] Gallon	MonoFoil [®] Ounces
9	0.03	4
18	0.06	8
25	0.09	12
34	0.12	16
52	0.19	24
78	0.28	36
99	0.36	46
148	0.53	68
200	0.72	92
252	0.91	116
300	1.08	138
352	1.27	162
400	1.44	184

Application of **MonoFoil[®] Antimicrobial** must be done separately from normal washing. Do not mix with regular detergent. **MonoFoil[®]** must be applied to clean garments. If the garments are dirty, wash them prior to the antimicrobial treatment. Shake container well before each use. Load clean laundry in the washer and select the normal wash cycle.

Manual Load Directions: Start wash cycle. When the wash reaches the final rinse stage, add above guideline amount of **MonoFoil[®]** to the washing machine using a measuring device and complete the wash cycle.

Automatic Load Directions: If the washing machine is equipped with a fabric softener dispenser, add above guideline amount of **MonoFoil[®]** into the dispenser using a measuring device. Start wash cycle. Note: to preserve the efficacy of the application, make sure the dispenser is free of any prior product residue before adding the **MonoFoil[®]**.

Front Load Directions: Add above guideline amount of **MonoFoil[®] Antimicrobial** into the final rinse water of the washing cycle. Do not use **MonoFoil[®]** in conjunction with any other laundry product. For front loaders, pour **MonoFoil[®]** into dispenser for the final rinse cycle. Dry garments as usual. Dry laundry in a dryer at normal drying setting.



Texon Antimicrobial

DEFEATING MICROORGANISMS

